

AFB-350

Single Tx Antenna Fiber Box



Instructions :

- 1-Power : 12-36VDC-15W (AC/DC converter or battery), linear PSU is advisable.
Consumption : 800mA (@Vin=12Vdc)
XLR4 wiring : 1(-) 2(NC) 3(NC) 4(+)
- 2-Fiber : Neutrik Opticalcon Duo APC or LC/APC fiber optics cables linked to fiber transmitter (ATH-200)
- 3-RF out : Tx antenna output (50ohms)
- 4-Led indications :
- Power : Green color lights up when the device is on
 - Optical in : green colour indicates that an optical signal is detected
 - SWR : a built-in reflection bridge measure forward and reflected power.
 - green : low reflection, this is good
 - yellow : reflections occurred, is correct
 - red : too much reflections, check your cable, check your antenna or filter is in the good frequency range.